

SAT TV Multi-Switch

2x4 Satellite TV Multi-Switch

Installation Instructions



Connect a dual output LNB to ports A & B this will provide both horizontal and vertical signals through out the complete installation. No power injector is required for this Mutli-Switch as the power is provided by the satellite receiver.